

Futura Leather Immersive Sound System

Model US13014M (Bluetooth Device Name: “Doer”)

Welcome

Thank you for choosing the **Futura Leather Immersive Sound System**—an advanced furniture-integrated audio experience designed to bring cinematic sound directly to your living space. This innovative system features **built-in speakers** seamlessly integrated into your **sofa, loveseat, and recliner**, creating a rich, spatial sound field without the need for external speakers.

Using **Broadcast Bluetooth® technology**, the system synchronizes wireless audio across all connected furniture pieces for a true surround sound effect. Setup is quick and simple, typically taking **10–15 minutes**.

Before You Begin

Please review the following important notes before setup:

- **TV Compatibility:** Your television must support Bluetooth audio output (most modern smart TVs do). Popular brands such as Samsung, LG, Sony, and Vizio are compatible.
 - **System Model:** The system identifier is **US13014M**, which may appear as “**Doer**” when pairing via Bluetooth.
 - **Positioning:** Ensure your furniture is placed within **30 feet (10 meters)** of your television, with minimal obstructions.
 - **Preparation:** Have your TV remote available and ensure nearby power outlets are accessible.
-

Setup Instructions

Step 1: Prepare and Power On the Furniture

1. **Position the Furniture:**
Arrange your sofa, loveseat, and recliner in their desired locations, ensuring they are within Bluetooth range of your TV.
2. **Connect Power Cables:**
 - Locate each piece’s power cord (typically under or behind the unit).
 - Plug into grounded outlets or a surge protector.

- Verify power: indicator lights on the main control panel should illuminate once powered.
- 3. **Power On the System:**
 - On the **sofa (main unit)**, locate the **main control panel** in the drop-down compartment at the center back.
 - Press the **Power** button. You should hear a soft chime or see LED lights confirm activation.
 - The loveseat and recliner will automatically sync with the sofa via Broadcast Bluetooth—no additional steps required.

Tip: If there are no lights or sound, double-check your power connections and try a different outlet.

Step 2: Enable Bluetooth on Your Television

1. **Turn On the TV** and navigate to a source with audio (e.g., Netflix, streaming app, or HDMI input).
2. **Access Settings:**
 - Open your TV's **Settings** or **Menu** (often shown as a gear icon).
 - Go to **Sound**, **Audio**, or **Bluetooth** (menu name varies by brand).
3. **Enable Bluetooth Pairing:**
 - Select **Bluetooth Devices** → **Add Device** or **Pair New Device**.
 - Ensure Bluetooth is **turned on** and your TV is in pairing mode.

Tip: If your TV offers a dedicated Bluetooth audio mode, select it to route all audio wirelessly.

Step 3: Pair the Sound System

1. **Locate the Device:**

In your TV's list of available devices, look for **US13014M** or **"Doer."**

 - If not visible, ensure the system is powered on and within range, then refresh the scan.
2. **Initiate Pairing:**
 - Select **US13014M** or **"Doer."**
 - Wait for the confirmation message such as *"Connected"* or *"Paired Successfully."*
3. **Test the Connection:**
 - Play audio or video content.
 - You should hear immersive, directional sound from your furniture's built-in speakers.
 - Volume, bass, treble, and vibration can all be adjusted via the **sofa's control panel**.

Congratulations! Your immersive sound system is now ready for use.

Additional Features

- **Volume & EQ Controls:**
Fine-tune your listening experience through the sofa’s control panel—adjust bass, treble, or vibration intensity to your preference.
 - **Multi-Device Pairing:**
The system can connect to smartphones or tablets via Bluetooth (one device at a time). To switch, disconnect from your TV first in your TV’s Bluetooth settings.
 - **Maintenance Tips:**
 - Keep the control panel closed when not in use to prevent dust buildup.
 - Avoid direct sunlight or moisture exposure.
 - Clean with a soft, dry cloth only.
-

Troubleshooting Guide

Issue	Possible Cause	Recommended Solution
No Power Indicators	Loose power cord or faulty outlet	Check connections, test outlet with another device, and try again.
Device Not Found in Bluetooth Scan	Out of range or interference	Move TV and furniture closer; temporarily disable nearby Wi-Fi or microwaves. Restart both TV and system.
Connection Fails or Drops	Interference or outdated firmware	Remove (“Forget”) the device from your TV’s list, rescan, and repair. Ensure TV firmware is up to date.
No Sound from Furniture	TV audio not routed to Bluetooth	In your TV’s settings, set Audio Output to Bluetooth or External Speaker . Test with Bluetooth headphones to confirm output path.
Low Volume or Distortion	Sync delay or Bluetooth lag	Disable Dolby/Surround modes in your TV’s audio settings. Reset the system by holding the power button for 10 seconds.
Device Name Mismatch (“Doer” vs. “US13014M”)	Display variation	Both refer to the same system. If neither appears, verify the model with your purchase receipt.

Customer Support

If you continue to experience difficulties, please contact **Futura Leather Customer Care** for assistance.

Email: support@futura leather.com

Phone: 1-800-555-FUTURA

Hours: Monday–Friday, 9 AM – 6 PM EST